

yellobrik

Technical Specifications

Auto detect bit rate (10/100/1000), or force to 10Mbit/s for each port Automatic crossover detection or force manually for each port Port speed / activity LED indication (next to Ethernet port) I x fiber optic input, 1 x fiber optic output SMF (singlemode) using LC/PC connection EEE 802.3z (1000BASE-X Gbit/s Ethernet over Fiber at 1Gbit/s (125 MB/s) Singlemode Version: OET 1514 Fransmitter: 1310nm (-3dBm) Receiver: 1260nm to 1620nm (-23dBm)			
Port speed / activity LED indication (next to Ethernet port) I x fiber optic input, 1 x fiber optic output SMF (singlemode) using LC/PC connection EEE 802.3z (1000BASE-X Gbit/s Ethernet over Fiber at 1Gbit/s (125 MB/s) Singlemode Version: OET 1514 Fransmitter: 1310nm (-3dBm)			
1 x fiber optic input, 1 x fiber optic output SMF (singlemode) using LC/PC connection EEE 802.3z (1000BASE-X Gbit/s Ethernet over Fiber at 1Gbit/s (125 MB/s) Singlemode Version: OET 1514 Fransmitter: 1310nm (-3dBm)			
5MF (singlemode) using LC/PC connection EEE 802.3z (1000BASE-X Gbit/s Ethernet over Fiber at 1Gbit/s (125 MB/s) Singlemode Version: OET 1514 Fransmitter: 1310nm (-3dBm)			
Singlemode Version: OET 1514 Fransmitter: 1310nm (-3dBm)			
Fransmitter: 1310nm (-3dBm)			
Max. Distance: 10km(6.2 miles)*			
Nultimode Version: OET 1514-MM Fransmitter: 850nm (-2dBm to -7 dBm) Receiver: 850nm (-15dBm) Max. Distance: 550m(1800 feet)*			
FX and RX active LEDs on side of module			
+12V DC @ 1.7W nominal (without SFP) Input range: 7 - 22V DC			
Power LED on side of module			


We are constantly adding more yellobrik modules. Please visit our website for the latest product updates. www.lynx-technik.com

LYNXTechnik AG | www.lynx-technik.com

yellobrik[®] Quick Reference

OET 1514

Ethernet to Fiber Transceiver (switch)



Connections

The module operates as a 3 port ethernet switch with two standard RJ45 electrical ethernet ports and an SFP port for twin fiber connectors.



If not connected, use the included dust plug to protect the SFPs optical connection from dust and eves from the laser light.

Operation

The module maintains a constant fiber communication speed regardless of the speed of the 2 electrical ports. The electrical ethernet ports can be configured indepenently using the module dip switch if required. This facilitates the use with older legacy electical networks.

Auto	0	0	10Mbit – Force Speed	
Auto	0	0	Manual Crossover	
	_		Yes 🚽	
			10Mbit – Force Speed	
			Manual Crossover	
No	0	0	Yes - Crossover	

The electrical port speeds can be set to automatic mode (10/100/1000 Mbit/s) or forced 10Mbit/s if required. It is also possible to configure automatic or manual crossover for the electrical ports (forced manual crossover is sometimes needed for older networks).

Note: TX LED is continuously ON as soon as an SFP is inserted and the device is powered on. The purpose is to protect eyes and other optical instrument, as the SFP laser is active.

Power Lead Strain Relief

The module has a small hole in the case which is located above the power connection. This prevents the power lead being accidentally pulled out. Use the supplied tie-wrap and secure the lead as shown.



Power

The module requires a clean 12V DC (7-22V DC) power source. An LED is provided to confirm power is connected. A 12V DC power supply is included with the module. Power consumption information can be found in the technical specifications table.

Optional Mounting Solutions

The optional RFR 1001 mounting bracket can be used to mount the module on any surface or on 19" rack rails.









mounted vellobriks.



USB Connection

The USB interface of the module is used for monitoring and firmware updates. To update a yellobrik, power it on and connect it to a PC or Mac running LYNX control software (yelloGUI or LynxCentraal) with the provided USB cable.



LYNX Centraal.



You will be notified if a new firmware is available.

Online Product Page

For additional information on the device visit our website via the QR code to the right. This website shows the most recent datasheets, quick reference guides and more.

If you encounter issues or have questions regarding the device please visit our support section.

